

## Malla Reddy Engineering College



(Autonomous)

(An Autonomous institution, Autonomy granted by UGC and affiliated to JNTUH, Accredited by NAAC with 'A' Grade, Accredited by NBA (2008-11) & Recipient of World Bank Assistance under TEQIP phase – II S.C.1.1for the period (2011-14))

Maisammaguda, Dhulapally (Post. Via. Kompally), Secunderabad – 500 100.



## LAB MANUAL

## **ENGINEERING MECHANICS**

I B. TECH- I SEMESTER

Subject Code: 80305

Academic Year 2018-19 Regulations: MR18

NAME:		
USN :		
BATCH:	SECTION:	

2018-19 Onwards (MR-18)	MALLA REDDY ENGINEERING COLLEGE (Autonomous)		B.Tecl Semes	
Code: 80305	ENGINEERING MECHANICS LAB	L	T	P
Credits: 1.5	ENGINEERING MECHANICS LAD	-	-	3

**Prerequisites: Engineering Physics** 

**Course Objectives:** Student will be able to learn and understand the various basic concept and principles of Mechanics like Force & Resultant.

## **List of Experiments**

- 1. Triangle law and polygon law of forces apparatus.
- 2. Support reaction for a beam apparatus.
- 3. Coefficient of friction apparatus.
- 4. Flywheel apparatus.
- 5. Moment of disc apparatus.
- 6.Jib Crane
- 7. Equilibrium of non concurrent forces apparatus.
- 8. Universal force table.
- 9. Screw jack apparatus.
- 10. Compound pendulum.
- 11. Worm and worm wheel apparatus.
- 12. Differential wheel and axle apparatus.

## **Course outcome:**

At the end of the course, students should be able to:

	Course Outcome	Level of learning	Bloom's Taxonomy Level
CO1	Verify law of Force Polygon and law of Moments using Force Polygon and bell crank lever apparatus and also study Parallel Force apparatus.(Simply supported type).	3	Analyzing
CO2	Determine mechanical advantage, Velocity ratio and efficiency of	2	Analyzing

	a screw jack.		
CO3	Evaluate co-efficient of friction between trolley (slider) and an	3	Analyzing
	inclined plane.		
CO4	Verify the error percentage for the universal force table.	3	Analyzing
CO5	Determine the moment of inertia of the fly wheel.	2	Analyzing

## **INDEX PAGE**

SI.	Name of the Experiments		Dates		Manual Marks	ord (S	Signature(Student	Signature(Faculty)
No	Name of the Experiments	Conduction	Repetition	Submission of Record	Manua	Record Marks	Sign )	Sign
A								
	Average	<u> </u>						

Note: If the student fails to attend the regular lab, the experiment has to be completed in the same week. Then the manual/observation and record will be evaluated for 50% of maximum marks.

## **General Instructions to Students**

- Students are informed to present 5 min before the commencement of lab.
- Students must enter their name in daily book before entering into lab.
- Students must leave Foot wares before entering lab.
- Students must not carry any valuable things inside the lab.
- Students must inform lab assistant before He/She uses any computer.
- Do not touch anything with which you are not completely familiar. Carelessness may not only break the valuable equipment in the lab but may also cause serious injury to you and others in the lab.
- For any software/hardware/ Electrical failure of computer during working, report it immediately to your supervisor. Never try to fix the problem yourself because you could further damage the equipment and harm yourself and others in the lab.
- Students must submit Record book for evaluation before the commencement of lab.
- Students must keep observation book (if necessary).
- Students must keep silent near lab premises.
- Students are informed to follow safety rules.
- Students must obey lab rules and regulations.
- Students must maintain discipline in lab.
- Do not crowd around the computers and run inside the laboratory.
- Please follow instructions precisely as instructed by your supervisor. Do not start the experiment unless your setup is verified & approved by your supervisor.

## **CONTENTS**

Sl. No.

## **Title**

- 1. Triangle law and polygon law of forces apparatus.
- 2. Support reaction for a beam apparatus.
- 3. Coefficient of friction apparatus.
- 4. Flywheel apparatus.
- 5. Moment of disc apparatus.
- 6.Jib Crane
- 7. Equilibrium of non concurrent forces apparatus.
- 8. Universal force table.
- 9. Screw jack apparatus.
- 10. Compound pendulum.
- 11. Worm and worm wheel apparatus.
- 12. Differential wheel and axle apparatus.


# Polygon Law of Forces


**ENGINEERING MECHANICS LAB** 

 $\frac{1}{2}$ 

**I SEM** 

 $(V_{1}, V_{1}, V_{1}, V_{2}, V_{1}, V_{1}, V_{2}, V_{2},$ 






			PERCENTAGE ERROR
s. no.	FORCES	CALCULATED	
	( total weights of pans)	RESULTANT T <sub>1</sub>	$\frac{\mathbf{T} - \mathbf{T}_1}{\mathbf{T}} \times 1000$
			100

- Procedure:


  1. Set the board in a vertical plane & fix the paper sheet with drawing pins
  2. Pass a thread over two pulleys
  3. Take a second thread & tie the middle of this thread to the middle of first thread
  4. Pass the ends of second thread over the other set of two pulleys
  5. Take a third thread & tie its one end to the point of first two threads
  6. Attach pams to the firse ends of the threads
  7. Place the weights in the pans in such a manner that the knot comes approximately in the centre of the paper.
  8. Mark the line of forces & write down the magnitude of forces
  9. Remove the paper from the board & produce the line to meet at centre point O
  10. Select a suitable scale & draw the vector diagram by moving in one direction, draw a b parallel to A B & cut it equal to force P, draw be parallel to B C & cut it equal to Q; draw c d parallel to C D & cut it equal to force R; draw d e parallel to D E & cut it equal to T then percentage error is found as follows.

  Observations:


  Page 9 of 67



			-	· ~	~	1		<u> </u>		
	P	Q	R	S	T					
1.										
2.										
3.										
	recaution	ıs :-	1			.1				
		, ,			ch the bo					
			_			on the threa				4.4.
		ile calcul weight o			rce in eac	h case the w	eignt of th	ie pan sno	ouid de ado	ueu to
		_	_		at rest wh	en the lines	of action of	of force sa	re marked	
	5. All	the pulle	ys should	d be free	from fric	tion				
1		D D	GR	<b>\</b>	N E		P <b>P</b> /			
		D D	G R		NE		<b>P</b> [ <b>P</b> /			
						O N				



	Parts D	etai	ils
1	Wooden Base	6	Sliding Hook Brackets
			Extinction Balance With
2	Iron Strip	7	Chain
3	Upright Bar	8	Hanging Chain With Hook
4	Cast Aluminum Bracket	9	Nut & Washer
	Tie Bar With Compression		Screw For Fixing The Iron
5	Balance	10	Strip



- AIM: To calculate the stresses in various member of the jib crane and find the % age error between the calculated and the observed values.

  Things required::

  > Jib Crane Apparatus

  > Weights

  Procedure::

  1. Note the zero error in the compression balance and the spring balance.


  2. Suspend a wt (w) from the pt. A. Then measure AB, BC, AC, Draw the scale. Note. B is center of the compression balance and C s vertically above B. Fig. can serve as the vector or stress diagram also because it is a triangle (as any other triangle with sides parallel to it will be a similar triangle.

  3. Let w be represented by CB. Then BA will be represent stress in the Arm AC (Tie). Thus these are the calculated values (Note, we can do without the scale diagram and simple measure AB, AC and BC)

  4. Note the reading in the compression balance which will give the observed stress in the Arm AB, and tension in the spring balance given the observed force in the Arm AC. Find the %age error between the calculated and observed value.


5. We have to know whether arms AB and AC are in compression or in tension. Now the pt. A is in equilibrium acted upon by the forces exerted by arms AB AC and wt (w) as show in FIG 3. Lets first consider the nature of the force in the arm AB. The opposite force is exerted by the pt A on the member AB. As the member AB is in equilibrium another opposite force is exerted by the pt Bon the member AB. Thus AB is in compression. Similarly it can be show that the arm AC is in tension i.e. it is stretched.

# SINGLE WORM WHIEL



 $oldsymbol{1}$ 

# SINGLE WORN WELL APPARATUS INSTRUCTION MANUAL AIM: To determine the efficiency of a worm and worm wheel apparatus and plot a graph between W & P and W & I). Serew jack Apparatus



WORKING:
As the pulley of the worm moves through n revolutions, n teeth of the wheel pass completely through the worm. If there are N teeth in the worm wheel, then N revolutions will have to be given to the pulley of the worm to rotate completely the worm wheel. So that if the effort applied at the pulley of the worm moves through N revolution the load is raised up by the a distance equal to the length of the circumference of the pulley of the worm wheel.

So that velocity ratio is

Nx circumference of pulley of worm
Circumference of pulley of worm wheel

SINGLE THREADED WORM:Specifications:

Starts: Single

Lead angle: 3° 35'

Pressure angle: 24°

STEW JACK APPARTALLS

Page 16 of 67

Normal Axial Pitch: 8mm

Pitch of two continuous threads: 21.5mm

THEORY:
If the worm is single threaded (i.e for one revolution of the wheel, the worm pushes the worm wheel through one teeth) then for one revolution of the effort pulley the distance moved by effort load =  $2\pi l$ The load drum will move through  $\frac{1}{L}$  revolution

Therefore, distance moved by the load on load drum =  $2\pi l$ And velocity ratio(V.R) =  $\frac{distance moved by P}{distance moved by W}$   $V.R = \frac{2\pi l}{2!!!} = \frac{lT}{r}$ Mechanical advantage =  $\frac{W}{P}$ Efficiency,  $\eta = \frac{M.A}{V.R}$ 

$$V.R = \frac{2\pi l}{\frac{2\pi r}{T}} = \frac{lT}{r}$$

Efficiency, 
$$\eta = \underline{M.A}$$
  
V.R

- PROCEDURE:
  1. Wrap the string round the pulley of the worm the free end of which is to be tied to the effort.

  2. Wrap another string to carry the load round the pulley the worm wheel in such a manner that as the effort is applied the load is lifted up.

  3. Suspend a small weight (w) through the free end of the string and suspend another weight (p) through the free end of the first string which should just move the load upward.

  4. Note w and P, so that mechanical advantage is given by W

  P

  5. Increase the load (w) gradually and increase the effort (p) correspondingly and take in this way about seven readings.

  6. Measure the circumference of the pulley of the worm and also that of the worm wheel.

  7. The percentage efficiency is given by W x 100

  PV

  8. Plot a graph between w and p and w and.

  OBSERVATION:-


 $\overline{\mathcal{O}}$ 

- **1**. Circumference of pulley of the worm  $(2 \Pi R_1) = 39.25$  cm.
- **2**. Circumference of pulley of the worm wheel  $(2 \prod R_2) = 43.96$  cm.
- **3**. No of teeth in the worm wheel (N) = 120
- **4**. Velocity ratio =  $N \times 2\pi R_1$  $2\pi R_2$

## **OBSERVATION TABLE**

S. No.	Weight Lifted (W)	Effort Applied (P)	Mech. Adv. = W/P	Velocit <del>y</del> Ratio	% Efficiency W/PV x 100
1	2	180		107.14	
2	3	200		107.14	
3	4	250		107.14	
4	5	300		107.14	
5	6	350		107.14	


## **PRECAUTIONS:-**



$$I_O \ddot{\theta} = -Mgh \sin \theta$$

$$Ml^2\ddot{\theta} = -Mgl \sin \theta$$

$$\frac{Mgh}{I_O} = \frac{g}{l} \tag{1}$$



$$k_0^2 = hl (2)$$

$$k_0^2 = hl = h^2 + hh' (3)$$

$$k_O^2 = h^2 + k_G^2$$

$$k_G = \sqrt{hh'}$$
 (4)

• Width: 5 mm
• Thickness: 2.5 cm

Theory:

In Fig. 1, O is the point of suspension of the compound pendulum and G is its centre of mass; we consider the force of gravity to be acting at G. If h is the distance from O to G, the equation of motion of the compound pendulum is  $l_0 = -Mgh \sin \theta$ Where Lis the moment of inertia of the compound pendulum about the point O.


Comparing to the equation of motion for a simple pendulum  $Ma^2 \partial = -Mgl \sin \theta$ We see that the two equations of motion are the same if we take  $\frac{Mgh}{I_0} = \frac{g}{I} \qquad (1) \qquad \text{Figure 1}$ It is convenient to define the radius of gyration  $k_0$  of the compound pendulum such that if all the mass M were at a distance  $k_0$  from O, the moment of inertia about O would be  $L_n$ , which we do by writing  $I_0 = Mk_{02}$ Substituting this into (1) gives us  $k_0^2 = hl \qquad (2)$ The point O', a distance  $l_0$  from O along a line through G, is called the center of oscillation. Let h' be the distance from G to O', so that l' h+l'. Substituting this into (2), we have  $k_0^2 = hl = h^2 + hh' \qquad (3)$ If  $l_0$  is the moment of inertia of the compound pendulum about its centre of mass, we can also define the radius of gyration  $k_0$  about the centre of mass by writing  $l_0 = Mk_{02}$ .

The parallel axis theorem gives us  $k_0^2 = hl = h^2 + hh' \qquad (3)$ If  $l_0$  is the moment of inertia of the compound pendulum about its centre of mass, we can also define the radius of gyration  $k_0$  about the centre of mass by writing  $l_0 = Mk_{02}$ .


The parallel axis theorem gives us  $k_0^2 = h^2 + k_0^2$ Comparing to (3), we have,  $k_0 = \sqrt{hl} \qquad (4)$ If we switch h with h', equation (4) doesn't change, so we could have derived it by suspending the pendulum would have the same length l. Therefore the period would be the same as when suspension at O and at various points along the centere of oscillation would be the same as when suspension of O and the squivalent simple pendulum would have the same length l. Therefore the period would be the same as when suspension

$$T = 2\pi \sqrt{\frac{l}{g}}$$

$$g = \frac{4\pi^2 l}{T^2}$$



$$\partial l/\partial h = 1 - k_G^2/h^2 = 0$$



to any period, a straight line is drawn parallel to the X- axis from a given period T on the Y- axis, cutting the graph at four points A, B, C, D. The distances AC and BD, determined from the graph, are equal to the corresponding length I. The average length I = (AC-BD)/2 and IVT are calculated. In a similar way, IVT is calculated for different periods by drawing lines parallel to the X-axis from the corresponding values of T along the Y- axis, IVT should be constant over all periods T, so the average over all suspension points is taken. Finally, the acceleration due to gravity is calculated from the equation g= 4π²(UT²).

• T<sub>min</sub> is where the tangent EF to the two brunches of the graph crosses the Y-axis, At T<sub>min</sub>, the distance EF-I = 2ka can be determined, which gives us ka, the radius of gyration of the pendulum about its centre of mass, and one more value of g, from g= 4π²(Cke/T<sub>min</sub>).

• k<sub>G</sub> can also be determined as follows. A line is drawn parallel to the Y-axis from the point G corresponding to the centre of mass on the X-axis, crossing the line ABCD at P. The distances AP = PD = AD/2 = h and BP = PC = BC/2 = h are obtained from the graph. The radius of gyration kg about the centre of mass of the bar is then determined by equation (4). The average value of kc, over the different measured periods T is taken, and the moment of inertia of the bur about a perpendicular axis through its centre of mass is calculated using the equation I<sub>G</sub> —Mk<sub>G</sub>².

Performing The Simulation:

• Suspend the pendulum in the first hole by choosing the length 5 cm on the length slider.

• Click on the lower end of the pendulum, drag it to one side through a small angle and release it. The pendulum will begin to oscillate from side to side.


• Repeat the process by suspending the pendulum from the remaining holes by choosing the corresponding lengths on the length slider.

• Draw a graph by plotting distance d along the X-axis and time period T along the Y-axis. (A spreadsheet like Excel can be very helpful here.)

• Determine

No.of holes from A Distance of knife edge from A: (cm)  1 2 Mean (s)  1 Length of equivalent simple pendulum(cm)   Time period, T (s)    AC (cm)   BD   Mean (cm)   I    AC (cm)   BD   Mean (cm)   I    AC (cm)   Cm   Cm   Cm   I    SI.No   Mean (cm)   Respectively   Respective	from A edge from A: (cm)  Time for 10 oscillations (s)  period T (s)  1	raw grap	h:							
1. To find the value of 'g':  Length of equivalent simple pendulum(cm)  AC (cm)  BD Mean (cm) l  SI.No  1	<ol> <li>To find the value of 'g':         Length of equivalent simple pendulum(cm)         AC (cm) BD Mean (cm) l         AC (cm) (cm) l         25         3 do so so</li></ol>					Time for 1	0 oscillat	tions (s)		
SI.No  Length of equivalent simple pendulum(cm)  BD Mean (cm) l  AC (cm)   l  SI.No	SI.No Length of equivalent simple pendulum(cm) $(s)$ $(cm/s^2)$ $(cm/s)$ $(c$					1	2	309/25		
0,	<ul> <li>2. To find the radius of gyration and the acceleration of gravity (step 3 above):</li> <li>Radius of gyration about the centre of mass k<sub>G</sub> = EF/2 =</li></ul>	Length simple	of equiv	ralent n(cm)	Time period, 7	95 1 10 100 958	2 — 1.5 T— 1 —	A E		
	<ul> <li>Radius of gyration about the centre of mass k<sub>G</sub> = EF/2 =</li> <li>Acceleration of gravity, g= 4π²(2k<sub>G</sub>/T<sub>min</sub>²) =</li> </ul>	<u>:</u>					0	20	40 60 80	100


SI.No	Length simple p			Time period, T (s)	g (cm/s <sup>2</sup> )
	AC (cm)	BD (cm)	Mean l		



	12	2433	A STATE OF THE STA
SI.No	h=AD/2	h'=BC/2	$k_G = (hh')^{1/2}$
Results:			
	acceleration of gravity, g- radius of gyration of the p		. $m/s^2$ re of mass, $k_G =$ n
<ul><li>Mass of t</li><li>Moment</li></ul>	the pendulum $M = \dots$	Kg	mass, $I_G = Mk_G^2 = \dots$
Kgm <sup>2</sup>			

## COMBINED INCLINED PLANE & FRICTION SLIDE

## APPARATUS



Working Manual




STRUCTION MANUAL

AIM:-

Determination of Coefficient of friction by the inclined plane apparatus.

Screw Jack Apparatus
Page 27 of 67



## **APPARATUS:-**

- 1. Inclined plane
- 2. Sliding boxes with different surfaces
- 3. String
- **4. P**an
- 5. Thread

## **THEORY:-**

When a body slides upon another body, the property by virtue of which the motion of one relative to the other is related is called friction. The frictional force is directly proportional to the normal reaction 'N'.

$$F = \mu N$$
 or  $\mu = F \over N$ 

Suppose a body of weight W is to be lifted by inclined plane & this requires effort P. when this load just move upward a frictional force F acts downward which oppose its motion.

Component of load W parallel to the plane = W  $\sin \alpha$ 

Component of load W perpendicular to the plane =  $W \cos \alpha$ 

Considering equilibrium parallel to the plane

$$P = F + W \sin \alpha$$
  
 $F = P - W \sin \alpha$  .....(i)

Considering equilibrium perpendicular to the plane

$$N= W \cos \alpha$$
 .....(ii)

From (i) & (ii)

Co - efficient of friction,

$$\mu = \frac{\mathbf{F}}{\mathbf{N}} = \mathbf{P} - \mathbf{W} \sin \alpha$$

$$\mathbf{W} \cos \alpha$$

\[
 \mu = \forall \text{P} = \text{P} - \text{W} \text{sin}\alpha}{\text{W} \text{Cos}\alpha}
\]

Mechanical advantage (M.A.) = \( \text{W} \)

Velocity ratio (V.R.) = \( \frac{\text{distance moved by effort}}{\text{Distance moved by load}}
\]

Let effort P comes down through one centimeter, movement of the load along the plane = 1 cm

Vertical uplift of load = 1 x \text{sin}\alpha

V.R. = \( \frac{1}{1 \times \text{sin}\alpha} \) = \( \text{cosec}\alpha

\[
 \text{W efficiency} = \frac{\text{M.A.}}{\text{V.R.}} \]

\*\* a 100

V.R.

\*\*Strew lack Apparatus\*\*

\*\*Page 30 of 67\*\*

\*\*Pa

$$V.R. = \frac{1}{1 \times \sin \alpha} = \csc \alpha$$

% efficiency = 
$$\frac{M.A.}{V.R.}$$
 x 100

- PROCEDURE: 
   Take the inclined plane apparatus & keep it first horizontal and put the slider on it.
   Increase the inclination of inclined board gradually till the slider just begins to slide downwards on it.
   Note the angle in this position. This is called angle of repose.
   Place the slider on the plane with the desired angle α.
   Tie the slider to the pan with the help of thread passing over the pulley.
   Put the weight in the pan till the slider just start moving, note down the weight.
   Measure the angle of inclination from the scale provided & finds the value of μ.
   Calculate M.A., V.R., efficiency.

# OBSERVATIONS:-

S. No.	Total weight of	Weight of pan +	$\mu = P - W \sin\alpha$ $W \cos\alpha$	$\mathbf{M.A.} = \frac{\mathbf{W}}{\mathbf{P}}$	V.R.= cosecα	% Efficiency
777777	the slider W (grams)	weight in				
	125	40	0.15	3.125	5.75	54.34
2.	125	65	0.35	1.92	5.75	33.39
10. <b>2</b> 10.0 10.0 10.0 10.0 10.0 10.0 10.0 10.	125	115	7.65	1.08	5.75	18.72
	150	80	0.37	1.87	5.75	32.6
70.74.00.00.00.00.00.00.00.00.00.00.00.00.00	200	110	0.38	1.81	5.75	31.62
6. 7. A.	150	67	0.28	2.23	5.75	38.93
7.	200	115	0.41	1.73	5.75	30.24
8,	350	155	0.27	2.25	5.75	39.27
9.5	150	62	0.24	1.73	5.75	30.24

Screw Jack Apparatus


## **PRECAUTIONS:-**

- 1. The plane should be clean & smooth.
- **2.** The guide pulley should move freely. It should be lubricated to make it frictionless.
- **3.** Weight should be added gently in pan.
- **4.** The slider should just begin to move slowly, it should not move abruptly.
- **5.** The direction of thread should be parallel to the inclined plane.

Screw Jack Apparatus
Page 33 of 67


777		
5		
2		
5		
2		
5		
2		
5		
2		
5		
2		
5		
2		
5		
2		
5		
2		
5		
3		
5		
3		
5		
3		
5		
3		
5		
3		
5		
3		
5		
5		
2		
5		
2		
5		
2		
5		
2		
5		
2		
5		
2		
5		
3		
$\mathcal{L}_{\mathcal{L}}$		
3		
5		
3		
5		
2		
5		
2		
5		
2		
5		
2		
5		
2		
5		
2		
5	Screw Jack Apparatus	Page 34 of 67
777		

# MOURN'S OF INERTIA OF PLYWING



Working Mainual

MOMENT OF INERTIA OF FLYWHEEL APPARATUS				
CONTENTS:	Page No.			
AIM	02			
APPRATUS USED	02			
DESCRIPTION	03			
PROCEDURE	04			
MATHEMATICAL CALCULATION	05			
OBSERVATION	07			
PRECAUTIONS	08			
	Page 36 of 67			



1. Fly wheel
2. Meter scale
3. Vernier calipers
4. Stop watch
5. Weight

DESCRIPTION OF APPARATUS:
A flywheel is a large heavy wheel, through the center of which passes a long cylindrical axle. The center of gravity lies on its axis of rotation so that when it is mounted over ball bearing, it comes to rest any desired position.

To increase the moment of inertia, it is usually made thick at the rim.

To count the number of revolution made by the wheel, a lime is marked on the circumference. A string is wound on the axle, attached to the peg carries a mass M.

THEORY:

When a weight is suspended to the free end of a cotton string which is wrapped round tin: shaft and the other end of which is tied to the shaft and it is allowed to fall to touch the ground then P.E. energy possessed by the falling weight has partly been used to give motion to the fly wheel and partly used in overcoming frictional resistance present in the bearings.

- Initial Potential Energy (P.E.)=Wxh when h is the height of the weight from the level ground.
   Initial Kinetic energy (K.E.) = 0. Final P.E = 0.
   Final (K.E) = ½ (w/g) v² + ½ I (w² / g) where ½ (w/g) v² is the K. E of the falling wt. And ½ I (w²/g) is the K. E. of the fly wheel and shaft combined and w is the final angular velocity of the wheel or of the shaft.
   Work done due to frictional resistance = F x h where F is the force of friction acting tangentially to the shaft.
   From law of conservation of Energy we can write W x h = ½ (w/g) v² + ½ I (w² / g) + F x h
   ≥ 2g(W · F) x h = W v² + I v²
   ≥ 1 = (W F) x 2gh W v²
   W²
   But v (final velocity) is given by the formula (u+v)/2 = h/2 where t is the time taken for the weight to fall a distance h so that h/t is the average velocity.
   PROCEDURE: Attach a mass M (about 500 grams) to one ned of the thin thread and loop is made at the other end which is fastened at the peg.
   The thread is wrapped evenly round the axle of wheel.
   Allow the mass to descend slowly & count the number revolution N<sub>1 during</sub> descent.

$$W \times h = \frac{1}{2} (w/g) v^{2} + \frac{1}{2} I (w^{2} / g) + F \times h$$

$$=> 2g(W - F) \times h = W v^{2} + I v^{2}$$

$$=> I = (W - F) \times 2gh - W v^{2}$$

$$w^{2}$$

 $v_{i}$ 

4. When the thread has unwound itself & detached from the axle after N; turns, start the stop watch. Count the number revolution before the flywheel comes to rest & stop the stop watch. Thus N<sub>2</sub> are known.

5. With the help of vernier calliper, measure the diameter at several point. Thus find R.

6. Repeat the experiment with three different masses.

7. Calculate the value of I using the given formula.

MATHEMATICAL CALCULATIONS:

Moment about axis ox,

Consider an elementary ring of radius 'x' and thickness dx

Moment of inertia of this elementary ring about axis OX

= mass x (radius)<sup>2</sup>


2


1 a pinx dx

Taking mnt of inertia about OX ie integrating the above equation

Iox = Mr

Screw Jack Apparatus





$$= \frac{\text{mass x (radius)}^2}{2}$$

$$I_{ox} = Mr^{2}$$

By symmetry 
$$I_{oy} = M(r)$$

			4			
			O			
	Ву	symmetry I <sub>oy</sub>	$= \underbrace{M(r)}_{4}$			
	Similarl	y for axis OZ				
	•	M.O.I	= mass x (	(radius)	2	
	Taking 1	mnt about OZ	<b>A</b>	`		
		$ m I_{oz}$	$= \underbrace{p\pi r}_{2}$			
			= $Mr$			
			2			
	OBSERVA1	,		1.5	[m. 0.77]	
S.n	Total load	No. of	No. of	Mean No	•	Mean
		,	revolutions	Mean N <sub>2</sub>	Times of N <sub>2</sub> revolution T seconds	Mean sec
S.n	Total load applied M	No. of revolutions of flywheel before the mass	revolutions of flywheel to come to		revolution	
S.n	Total load applied M	No. of revolutions of flywheel before the mass deattached	revolutions of flywheel to come to rest after		revolution	
S.n	Total load applied M	No. of revolutions of flywheel before the mass	revolutions of flywheel to come to		revolution	
S.n	Total load applied M	No. of revolutions of flywheel before the mass deattached	revolutions of flywheel to come to rest after mass deatached N <sub>2</sub>		revolution T seconds	
S.n o	Total load applied M (k.g.)	No. of revolutions of flywheel before the mass deattached N <sub>1</sub>	revolutions of flywheel to come to rest after mass deatached N <sub>2</sub> 53	N <sub>2</sub>	revolution T seconds	sec
S.n	Total load applied M	No. of revolutions of flywheel before the mass deattached	revolutions of flywheel to come to rest after mass deatached N <sub>2</sub> 53 59		revolution T seconds 1.25 1.37	sec
S.n o	Total load applied M (k.g.)	No. of revolutions of flywheel before the mass deattached N <sub>1</sub>	revolutions of flywheel to come to rest after mass deatached N <sub>2</sub> 53 59 62	N <sub>2</sub>	revolution T seconds 1.25 1.37 1.38	
S.n o	Total load applied M (k.g.)	No. of revolutions of flywheel before the mass deattached N <sub>1</sub>	revolutions of flywheel to come to rest after mass deatached N <sub>2</sub> 53 59 62 107	N <sub>2</sub>	1.25 1.37 1.38 2.05	1.3
S.n o	Total load applied M (k.g.)	No. of revolutions of flywheel before the mass deattached N <sub>1</sub>	revolutions of flywheel to come to rest after mass deatached N <sub>2</sub> 53 59 62	N <sub>2</sub>	revolution T seconds 1.25 1.37 1.38	sec


3.	2	12	157 161 158	158	2.17 2.23 2.20	2.20
----	---	----	-------------------	-----	----------------------	------

# **PRECAUTIONS:-**

- Note the time accurately to the fraction of a second 1.
- 2. Note the value of F when the motion just begins and the fly wheel does not move with any acceleration
- Oil the bearings to reduce friction 3.
- 4. Overlapping of the string should be avoided
- Note the time thrice for the same weight (W) 5.

Lunn		<u> </u>
5		
3		
5		
5		
5		
3		
5		
5		
2		
5		
3		
5		
3		
2		
5		
3		
5		
3		
2		
5		
5		
31		
5		
5		
2		
5		
3		
5		
3		
2		
5		
2		
5		
3		
5		
5		
2		
5		
3		
5		
3		
2		
5		
2		
5		
3		
5		
3		
5		
5		
2		
5		
5		
3	Screw Jack Apparatus Page 43 of 67	
$\langle V_{VVVV} \rangle$		


# MOMENTS DISC APPARATUS



Working Manual

MOMENTS DISC APPARATUS						
CONTENTS:	Page No.					
OBJECTIVE	03					
THEORY	04					
PROCEDURE	05					
OBSERVATION	06					
PRECAUTIONS	07					

# Ents disc apparati



- 4. Four pans
- 5. Slotted weight
- 6. Plumb line

# **THEORY & FORMULA USED:-**

The law of moment's states that if a number of coplanar forces acting on a rigid body keep it in equilibrium then the algebric sum of their moments about any point in their plan is zero.

In the moments disc apparatus, we use the hollow disc, pulleys, threaded pan, mirror scale, plumb line. All these things are adjustable. Due to use these apparatus make to ensure that the level of fixing threaded pan in a hollow disc should be equal. Requirement of plumb line to adjusting the apparatus at equal level in any positions.


The hollow disc & pulleys are moving either clockwise or anti-clockwise direction. All parts are adjusting on the straight beam which should be rigidly fixed on the base of the apparatus.

Screw Jack Apparatus
Page 47 of 67

# **PROCEDURE:-**

- (1) Put weights in the two pans A and B. such that W<sup>1</sup> is the weights in the pan A plus weight of the pan & W<sup>2</sup> weight in the pan B plus weight of pan B. Note down W<sup>1</sup> & W<sup>2</sup>.
- (2) Rotating disc should be placed at a centre point note the thread are showed at zero on the scale
- (3) Note down the distance X<sup>1</sup> and X<sup>2</sup>.
- (4) Now ( $W^1 \times X^1$ ) will be equal to ( $W^2 \times X^2$ ) that is both the clockwise and anticlockwise moments will be equal.
- (5) Take different sets of reading and find out the value of both the moments.


Screw Jack Apparatus
Page 48 of 67



Screw Jack Apparatus Page 49 of 67

5. NO.	Weight of pan + Weight in pan (W¹)	Weight of pan + Weight in pan (W²)	(c.m.)	X <sup>2</sup> (c.m.)	Percentage Error
1.	225	225	17	17	0
2.	225	225	17	16.6	0.4
3.	525	525	17	16.6	0.4
PRE	CAUTIONS:-				
(1	) Weights should be p	placed in the pans A ar ant the weights of the		tly.	


# Parallel Force Apparatus




PARALLEL FORCES APPARATUS


Screw Jack Apparatus
Page 51 of 67

AIM 03 THINGS REQUIRED 03 APPRATUS 03 THEORY 03 NOMENCLATURE 04 PROCEDURE 05 OBSERVATION 05 PRECAUTIONS 06			
THINGS REQUIRED  APPRATUS  O3  THEORY  O3  NOMENCLATURE  O4  PROCEDURE  O5  OBSERVATION  O5  PRECAUTIONS  O6	(	CONTENTS:	Page No.
APPRATUS 03  THEORY 03  NOMENCLATURE 04  PROCEDURE 05  OBSERVATION 05  PRECAUTIONS 06		AIM	03
THEORY 03  NOMENCLATURE 04  PROCEDURE 05  OBSERVATION 05  PRECAUTIONS 06		THINGS REQUIRED	03
NOMENCLATURE 04  PROCEDURE 05  OBSERVATION 05  PRECAUTIONS 06		APPRATUS	03
PROCEDURE 05  OBSERVATION 05  PRECAUTIONS 06		THEORY	03
OBSERVATION 05 PRECAUTIONS 06		NOMENCLATURE	04
PRECAUTIONS 06		PROCEDURE	05
		OBSERVATION	05
Parallel Force Appare		PRECAUTIONS	06
Parallel Force Appaire			
<u> </u>	Pan	millel Farre	Aกกกากการการการ
			<u> </u>
INSTRUCTION MANUAL		INSTRUCTION	M A N U A L



 $\overline{\mathcal{C}}_{\mathcal{C}}$ 






6.	Suspend three or four weights at different graduated division of the beam and find %age error between clockwise and anti –clockwise moments as before.
oser	vations:

	Suspend three or	_		_		beam and f	ind %age
<u>Observa</u>	tions:						
1. Z	Zero error in co	mpression b	alance No. 1	=			
2. Z	ero error in co	mpression b	alance No. 2 <sup>:</sup>	=			
TABLE: S.no	Weight W1	Weight	Reaction	Reaction	Reaction R3	Distance x	1 Distanc
		W2	R1	R2			X2
Take in	this manner at	oout seven re	eadings.				
2. V 3. S	ions: Zero error of the Veights should Slightly press l aking readings	not be put on the beam in	on the beam	with a jerk.			rts before

# SCREW JACK APPARATUS Screw Jack Apparatus Page 56 of 67



CONTENTS:	Page No.
<b>↓</b> Objective	02
Accessories Required	02
📥 Principle	02
<b>∔</b> Theory	02
Procedure	03
∔ Formula's	03
Nomenclature	04
Observation Table	04
<b>4</b> Calculations	04
Results	05
Precautions	05
<b>®nstruction</b> ⊂	Manual
SCREW JACK AP	PARATUS
AIM:-	
To determine the mechanical advantage, velo	city ratio and efficiency of a screw jack.



# **PRINCIPLE:**

Basically screw jacks are mechanical devices consisting of a heavy bottom metallic base or stand through which a screw mechanism is allowed to slide up and down through a circular path over a central axis. The load that is to be lifted is placed over the top "head" of the screw mechanism. The lifting movement or operation is made functional by applying an external physical force (using human hands) through a radial motion. A careful inspection of the screw movement (unwinding) through a single thread shows that the elevating movement follows the principle of an inclined plane.

Primarily two major factors are involved with the functioning of a screw jack, viz. the *weight* lifted and the *effort* applied.

# **THEORY:-**

Screw Jacks are devices used for raising and lowering heavy objects (weights) through external small manual labor. The article discusses the various calculations involved and explains the relation between weight which is to be lifted and the applied external force associated with these devices. Screw jacks were especially developed with the aim of solving the issue of raising and lowering large and heavy objects over ground levels easily through relatively smaller magnitudes of external effort. Screw jack works on the principle of screw & nut. It is used for raising heavy loads through small efforts.

A simple screw jack consists of a nut, a screw square threaded and a handle fitted to the head of the screw. The nut also forms the body of the jack. The load to be lifted is placed on the head of the screw. Here the axial distance between corresponding points on two consecutive threads is known as pitch. If ' $p_s$ ' be the pitch of the screw and 't' is the thickness of thread, then  $p_s = 2t$ .

# **PROCEDURE:-**

- Step 1 Wrap on string round of the flanged table and take it over a small pulley  $P_1$ . Effort load  $P_1$  is tied to the free end of this string.
- Step 2 Wrap another string around of the flanged table in the same direction in which the above string is wounded and take it over the other small pulley  $P_2$ .
- Step 3 Place a load 'W' on the flanged table.
- Step 4 Suspend weights over  $P_1$  and  $P_2$  to the free ends of both the strings coming over the two small pulleys. This load  $P_1$  and  $P_2$  should be increased gradually suitable to give a just upward motion to the load 'W' placed on the screw head.
- Step 5 Note down 'W' and 'P' to determine the M.A. i.e W/P. in this case effort weight would be added and it consider as total effort P;  $P_1+P_2$ .
- Step 6 Note down the distance fall down to lift the load l, measure by ruler.
- Step 7 Note down the distance covered by flanged table from initial to final, measure by ruler.
- Step 8 P<sub>1</sub> and P<sub>2</sub> should be noted down carefully.
- Step 9 Take 3-4 reading by the variation of the Loads and Efforts.

# **FORMULA'S:**

1. Circumference of the screw thread, =  $\pi$ \*D

$$= 3.14 * 3.05$$
  $(\pi = 3.14, D = 3.05 cm)$   
= 9.5

2. Mechanical Advantage = Load/Total Effort

$$M.A = \frac{W}{P}$$

Screw Jack Apparatus Page 59 of 67

3. Velocity Ratio = Distance moved by the effort/Distance moved by the load

$$V.R = \frac{2\pi l}{R}$$

4. Efficiency:

$$\%\eta = \frac{M.A}{V.R} X 100$$

# **NOMENCLATURE:**

 $\checkmark$  D : Diameter of Screw  $\checkmark$  p<sub>s</sub> : Pitch of the screw

✓ W : Load suspended on flanged table

✓ P : Total Effort Applied

 $\checkmark$  P<sub>1</sub> : Weight suspended pulley 1  $\checkmark$  P<sub>2</sub> : Weight suspended pulley 2

 $\checkmark$  l : Distance fall down to lift the load, i.e to turn the screw.

✓ R : Distance covered by flanged table in upward direction while weight

suspended via pulleys (By Ruler)

# **OBSERVATIONS:-**

Diameter of the rotational centre screw, D
 Pitch of the center long screw, p<sub>s</sub>
 Diameter of flanged table,
 Thickness of the flanged table
 = 30.5 mm
 = 2.5 mm
 = 20.5 cm
 = 20.5 mm
 = 20.5 cm
 = 41 mm
 = 4.1 cm

 $\triangleright$  No. of Pulley's, P<sub>1</sub>, P<sub>2</sub> = 2

Diameter of pulley
 Thickness of pulley
 = 52.5 mm
 = 52.5 mm
 = 10 mm
 = 1 cm

> Circumference of the flanged table = 9.5

➤ Load Lifted, W = Weight lifts
 ➤ Total Effort, (P<sub>1</sub> + P<sub>2</sub>), P = Efforts applied

**Note:** Take P<sub>1</sub> & P<sub>2</sub> as per applicant need.

# **CALCULATIONS:-**

- M.A. = W/P
- V.R. = Distance moved by effort/Distance moved by load
- Efficiency,% = (M.A./V.R) X 100

	Observations								Calculations		
Sr. No.	Load Lifted, W, Gms	Effort P <sub>1</sub>	Effort P <sub>2</sub>	Total Effort P <sub>1</sub> +P <sub>2</sub>	R mm	l mm	M.A.	V.R	Efficienc y		
1.											
2.											

RESULTS: -

# **PRECAUTIONS:-**

- **5.** There will be no overlapping of the strings.
- **6.** "W" should moves upward direction gently.

- 7. Load always place on flanged table.
- **8.** Effort should be applied carefully on both sides of hangers.
- 9. Both the pulleys are in parallel direction meanwhile performing.
- **10.** Lubricate the screw thread in every 3-4 weeks
- 11. Grease should be used as lubricant always.

# **SAMPLE READINGS:**

	Observations								Calculations		
Sr. No.	Load Lifted, W, Gms		Effort P <sub>2</sub>	Total Effort P <sub>1</sub> +P <sub>2</sub>	R mm	l mm	M.A.	V.R	Efficienc y		
1.	5000	400	300	700	10	120	5.55	75.3	9.4		
2.	5500	550	850	1400	10	130	3.62	81.68	4.37		

(All measurements constructed in shortest units)

**RESULTS:** The relationship between the efficiency and the load, the effort against the as shows that increase in load causes decrease in efficiency and increase in load causes increase in effort applied.

# **UNIVERSAL FORCE TABLE**



# INSTRUCTION MANUAL

# **UNIVERSAL FORCE TABLE**

**Screw Jack Apparatus** 

# AIM:-


• To Verify The Universal Force Table.

APPARATUS – Universal force table apparatus complete with freely moving and adjustable guide pulleys (Fig. 1), a ring with five strings, weight hangers, weight etc.

# **COMPONENTS:-**

- Thread Pulley
- Slotted Weight
- Thread/Rope
- Level Screw
- Central Ring


**THEORY**: Polygon law of forces states that if a number of coplaner forces acting on a particle are represented in magnitude and direction by the sides of a polygon taken in order, then their resultant is represented in magnitude and direction by the closing side of the polygen taken in order.



(FIG. 1 (f)) Universal Force Table

# PROCEDURE (It can be done on Gravesand Apparatus also)

- 1. Clamp the pulleys to the graduated disc of the force table and make it horizontal by adjusting the screws at its base.
- Tie each end of five strings to the circumference of a small ring and place it round the pin. Attach the other ends of the strings to the weight hangers, hanging over the pulley.
- 3. Put small weights on the weight hangers in such a manner that the ring is palced symmetrically round the axle and it does not touch the axle of the apparatus or the plane surface of the graduated disc.
- 4. Note the position of any one string on the disc and then find the angles between all the strings as  $\theta_1$ ,  $\theta_2$ ,  $\theta_3$ ,  $\theta_4$  and  $\theta_5$ .
- 5. Note down the magnitude of weights W<sub>1</sub>, W<sub>2</sub>, W<sub>3</sub>, W<sub>4</sub> and W<sub>5</sub> acting on the ring.
- 6. Draw the space diagram of the forces  $F_1 = W_1$ ,  $F_2 = W_2$ ,  $F_3 = W_3$ ,  $F_4 = W_4$  and  $F_5 = W_5$  as shown in Fig. 2 (a).
- 7. Draw the vector diagram abcde as shown in Fig. 2 (b). If the last force F<sub>5</sub> represented by the side ea falls short or is greater than the side which would complete the polygon, then measure the side which would complete the polygon and find the percentage error between the force F<sub>5</sub> and the force required to complete the polygon.



- Measure the angle a'ab i.e. α which would be equal to θ<sub>5</sub>. If they are different, then
  find the percentage error between t hese angles taking any of them to be true
  angle.
- Repeat the experiment with different set of weights.

# **PRECAUTIONS**

- The graduated disc should be made horizontal by adjusting the screws at its base.
   This can be checked with the help of a spirit level.
- 2. The ring should not touch the pin or the disc.
- 3. The pulleys should be frictionless i,e well lubricated.
- The positions of the strings should be carefully noted only after the system has come
  to rest completely.

# **Observation Table:**

# **Calculation Table:**

		R1)				
Sr. No	F=W1	F=W2	F=W3	F=W4	F=W5	F=W6
1	0	200	200	350	250	250

Sr.	Angles(θ) And Distances Ring To Wheel (cm)									RESULTANT (R)	
No	θ1	$L_1$	<b>0</b> 2	L <sub>2</sub>	<b>0</b> 3	$L_3$	<b>0</b> 4	L <sub>4</sub>	<b>0</b> 5	$L_5$	PYTHA. THEROM
1	0	22.3	72	21	120	20.8	170	22.0	28.8	23.5	49.06

Sr. No.	(R1) /	AND (α)	Percentage Error In	TOTAL %ERROR IN	
	F= SUM F	α	$A = \frac{R - F}{R} \times 100$	$B = \frac{\theta 5 - \alpha}{\theta 5} \times 100$	(B-A)
1	1.250 KG	72	97.45	75	22.45


# Differential Wheel And Axle Apparatus

# INSTRUCTION MANUAL

**Experiment:** To determine the efficiency of a wheel and differential axle and to plot a graph between W and P and (w and n)

# Things required:

- 1. Wheel & Differential Axle Apparatus
- 2. Weights
- 3. Cotton Thread



# Theory:

When the wheel moves through n revolutions the bigger and smaller axles also move through "n" revolutions. But while the string carrying weight is wrapped round the bigger axle completely it is released completely from the smaller axle the same time if the radius of the bigger axle is r1 and smaller axle is r2 then the string of length nr n (2 r1) is raised while a length nr n x 2r2 is lowered so that weight (w) which is supported by two segments of string is raised through a distance (2r1- 2r2)x n: while distance moved by the effort is 2R x n

Velocity Ratio (v) is 
$$2r \times n$$
 =  $2(2r)$  in term of the circumferences  $(2r_1 - 2r_2) \times n$  ( $2r_1 - 2r_2$ )

# Procedure::

1. Wrap the string round the smaller and bigger axles in such a manner that as it is released from the smaller axle in such a manner that is it released from the

Screw Jack Apparatus Page 66 of 67

- smaller axle it is wrapped round the bigger axle Tie another string round the wheel which will carry the error applied.
- 2. Suspend a smaller weight (w) through the hook of a small pulley going in between the two segment of the string as show in the diagram.
- 3. Suspend another weight (p) is to act as effort to just raise the load (w)
- 4. Note the wt (w) and effort P so that mechanical advantage is w/p.
- 5. Increase the weight (w) by a small amount and go on increasing the effort P gradually till he load (w) is just raised. Take in this way about seven readings.
- 6. Measure the circumference of smaller and bigger axles and of the wheel also, so that velocity ratio (v) is determined.
- 7. The % age efficiency is given by  $\underline{W\ X\ 100}$

PV

# **Observations:**

- 1. Circumference of smaller axle (2Πr1) = ----- cm
- 2. Circumference of bigger axle (2Πr<sub>2</sub>) =----- cm
- 3. Circumference of the wheel=  $(2\Pi R)$  =----- cm
- 4. Velocity ratio =  $\underline{2}\Pi\underline{R}$  =------( $2\Pi r_1 2\Pi r_2$ )

# Table:

S. No.	Weight Lifted (W)	Effort Applied (P)	Mech. Adv. = W/P	Velocity Ratio	% Efficiency W/PV x 100
1					
2					
3					
4					
5					

# **Precautions:**

- 1. Note the value of F when the motion just begins and the fly wheel does not move with any acceleration
- 2. Oil the bearings to reduce friction.
- 3. Overlapping of the string should be avoided.